## COMPREHESIVE LAB SAFETY CHECKLIST

The SAFETY & ENVIRONMENTAL COMPLIANCE DEPARTMENT has developed this form to assist and inform USA faculty and staff in identifying and correcting potential laboratory hazards. If you have any questions regarding the contents of this checklist, please contact the Safety & Environmental Compliance Department at 460-7070.

Revised: June 2018

	Yes	No	N/A
Laboratory Safety Assessment			
Chemical Hygiene Plan			
Have all departments and research labs reviewed the Chemical hygiene plan?			
<ul> <li>Are there any operations that require prior approval before beginning? (ex., Radiation Safety, Bio-safety committee)</li> </ul>			
Standard Operating Procedures (SOP's)			
Are there written SOP's covering the basic laboratory safety and hygiene practices? Check last review date			
<ul> <li>Is there a procedure for identifying particularly hazardous substances used in the lab? Do they have a department specific written procedure? Check last review date.</li> </ul>			
Training of laboratory personnel documented.			
Director/PI has utilized the provided Lab Training Matrix			
Training is current with Chemical Hygiene Plan & Hazard     Communication Standard			
Training is complete on Hazardous waste management			
<ul> <li>Training is complete on Blood borne Pathogen requirements</li> </ul>			
HAZARDOUS MATERIALS			
<ul> <li>Laboratory doors are labeled with emergency contact notification names &amp; numbers, hazards present &amp; necessary precautions</li> </ul>			
Labels are clean and intact on all chemical containers			
<ul> <li>Contents of stock solution buffer bottles are clearly identified (no laboratory abbreviations)</li> </ul>			
<ul> <li>Synthesized, unnamed chemical compounds are labeled by their reactants and possible products or by a useful generic description ( not by chemical structure only)</li> </ul>			
<ul> <li>Containers with non-hazardous substances (i.e., water) clearly labeled to avoid confusion</li> </ul>			
Chemical Controls	1		
Chemicals are not stored on laboratory benches is     excessive quantities			
<ul> <li>Expired or chemicals not used (for more than one year) are disposed of as hazardous waste</li> </ul>			

	Yes	No	N/A
<ul> <li>Defined area for highly toxic or carcinogens clearly marked</li> </ul>			
Secondary containment is provided for liquid chemicals			
<ul> <li>No hazardous materials are stored in, around under or above sinks</li> </ul>			
<ul> <li>Incompatible chemicals are segregated and stored in compatible hazard classes.</li> </ul>			
<ul> <li>All chemical containers are closed, except when actively adding or removing materials from them (i.e., no open funnels left in container)</li> </ul>			
<ul> <li>Containers of peroxide-forming chemicals are dated upon receipt and disposed of as hazardous waste (see Appendix B-Chemical Hygiene Plan)</li> </ul>	1		
<ul> <li>Safety Data Sheets (SDS) and laboratory chemical inventory are up-to-date and readily available</li> </ul>			
<ul> <li>Chemicals (liquids) are stored below eye level and not directly on the floor</li> </ul>			
Flammable & Combustible Liquids			
What quantities of Class 1A liquids are stored in the lab?			
<ul> <li>If there are more than 10 gallons of flammable liquids, doe the lab have the necessary fire protection systems available?</li> </ul>			
<ul> <li>How many flammable liquid storage cabinets are in the room and what is the capacity of each?</li> </ul>			
<ul> <li>Does the content of the storage cabinet exceed the maximum capacity of the cabinet?</li> </ul>			
<ul> <li>Flammable liquids (including flammable liquid waste) stored outside of a storage cabinet does not exceed 10 gallons?</li> </ul>			
No flammable liquid storage cabinet are in the hallway			
<ul> <li>Flammables are not dispensed from gravity-fed or botton dispensing containers—use lid mounted pumps (includin 5% Ethanol solutions)</li> </ul>			
Flammables are not stored in combustible containers			
<ul> <li>Ether and other highly flammable liquids are used away from sources of heat and ignition (including Bunsen burners in hoods and gas water heaters)</li> </ul>			
Flammable storage cabinets vented at bottom and door locked when not being accessed			

		Yes	No	N/A
Acute	y Hazardous Substances			
٠	Have all acutely hazardous substances been identified?			
•	Is a current inventory available with appropriate SDS information?			
•	Are areas or hoods where these substances are in use posted with a designated hazard sign?			
٠	Have special procedures for these substances been identified?			
٠	Are special procedures in practice? Verify procedures.			
•	Are all users adequately trained? Documentation available			
•	All compressed gas cylinders secured with cap in place, if not in use. Eight tank limit for non-flammable gases & five tank limit for flammable gases.			
•	All necessary PPP (personal protective equipment) available and used as needed.			
Radio	active Materials			
•	Stock materials of radioactive materials are secured against unauthorized removal?			
•	Do personnel wear lab coats, gloves and radiation dosimeters when handing materials?			
٠	Are all labs using radioactive materials registered with the Radiation Safety Office?			
Chemi	ical Waste Storage			
•	Have all chemical waste streams been identified as non- hazardous or hazardous and constituents been completely identified?			
•	Specific storage containers provided for (check applicable categories: () chemical waste () recyclable solvents () sharps () radioactive waste			
•	All hazardous chemical waste is arranged to be picked up by Safety & Environmental Compliance Department—not drain disposed or evaporated			
٠	All hazardous chemical waste is secondary contained.			
•	Solutions with heavy metals are collected separately and disposed of as hazardous waste			
•	The satellite hazardous waste accumulation storage area is clearly labeled			

		Yes	No	N/A
	ng for personnel handling hazardous waste is nented?			
	afety & Environmental Compliance Department is for waste pick up when containers are 3/4 full			
	e containers sturdy, compatible with the waste, lely checked for leaks and kept closed when not be			
Waste	e is segregated by compatible storage groups			
	here any non-hazardous chemicals that are drain sed? If so, what are they?			
Labeling				
with t	zardous waste containers have the proper labels he full chemical name or a list of full name and a ntage of each when waste mixtures are involved.			
conta	atellite accumulation area is clean with waste iners clearly marked, secondary contained and v stored			
drugs possik	esized, unnamed chemicals (including experimenta and chemicals) are labeled by their reactants and ble products or a useful generic description and ble hazardous. Do not label with chemical formulas			
BIOHAZARD	OUS WASTE			
Storage				
	biohazardous waste is bagged in 2 mil polyethylene as per the Bio-Medical Waste Management Plan	e		
with c	zardous liquid waste is either chemically treated lisinfectant, when generated, or directly afterwards roclaved.	5		
	ste is properly segregated as per the Bio-Medical Management Plan			
Labeling				
	port container labels are filled out with the date, of the generator and the name of the waste ssor			
Do the	e containers meet DOT and ADEM standards?			
Treatment				
Writte	en notebook log kept for autoclaved materials		1	

	Yes	No	N/A
<ul> <li>Log of autoclave validation runs includes: date, time, duration of run, pressure, temperature and number of ampoules included in waste treatment validation run</li> </ul>			
<ul> <li>Animal carcasses are properly bagged and labeled before being placed in designated freezers. Freezers are labeled?</li> </ul>			
<ul> <li>Non-hazardous animal bedding is double bagged and disposed of properly</li> </ul>			
<ul> <li>Bio-hazardous animal bedding is bagged, autoclaved (when necessary) and transported to the incinerator</li> </ul>			
All potentially infectious/contaminated sharps are placed in red, rigid plastic sharps containers			
<ul> <li>When the sharps container is <sup>3</sup>⁄<sub>4</sub> full it is sealed and placed is container for transport to disposal facility. Container must have appropriate packing and labeling</li> </ul>			
<ul> <li>All work surfaces are cleaned with a disinfectant solution that is active against the organisms in use. Clean and soiled storage areas must be separate. Procedures for cleaning and frequency must be defined. Verify procedure against practice</li> </ul>			
PERSONAL HEALTH AND SAFETY			
Food and Drink			
Food and drink are not permitted in laboratories			
<ul> <li>Food and drink are stored only in dedicated refrigerators/freezers and labeled "for food only"</li> </ul>			
Standard Practices			
<ul> <li>Employees wash areas of exposed skin prior to leaving the laboratory</li> </ul>			
Hands must be washed after removing gloves and before leaving laboratory			
<ul> <li>Hands must be kept away from face while working in the laboratory area. No cosmetic applications, taking medication, touching eyes, nose or mouth</li> </ul>			
HEALTH AND SAFETY EQUIPMENT			
Safety Showers and Eye Washes			
<ul> <li>Approved safety showers and eye washes provided within 10 seconds travel time from the work area for immediate use.</li> </ul>			
All eye washes and showers have unobstructed access	1		

	Yes	No	N/A
Units inspected monthly by the department and annually by Maintenance for proper functioning.	/		
Sign indicating location of safety shower and eye wash unobstructed.			
Personal Protective Equipment			
Have the correct PPE been selected based on a hazard analysis or manufacturer's recommendation?			
<ul> <li>PPE required for lab work: () Lab Coats, () Safety glasses with side shields/goggles, () Hearing protection, () Face Shield, () Proper foot-wear, () Gloves, () PPE for Radiological work, () Aprons</li> </ul>	)		
<ul> <li>All necessary equipment is available, in good condition, and properly used.</li> </ul>			
Laboratory Fume Hoods			
Storage inside of hood is kept to a minimum			
<ul> <li>Equipment in use does not interfere with proper functioning of the hood</li> </ul>			
All work is done at least 6 inches inside hood			
<ul> <li>Front sash is lowered below chin level when hood is in use</li> </ul>			
Certified within the last year (check certification located on front or side of hood)			
Hood has continuous flow monitor			
• The back ventilation slot is open a minimum of 2 inches			
Drains are protected from hazardous materials entering			
Biological Safety Cabinet (i.e., Laminar flow hoods)			
Certified within the last year (check certification located on front or side of hood)			
Proper type of hood for work being conducted			
• Equipment is properly labeled for the hazard present (radiation, UV,), Manufacturer approved for hazard.			
Hood ducted per manufacturers and ASHRA requirement and meet the CDC/NIH bio-safety specifications	ts		
Compressed Gas Cylinders			
Cylinders stored in well protected, well vented and dry locations away from combustible materials			

	Yes	No	N/A
<u></u>			
<ul> <li>Storage space is secured from damage either by passing or falling objects or subject to tampering by unauthorized persons.</li> </ul>			
<ul> <li>Cylinders are secured to a rigid structural component of the building with chains located 2/3 the height of the cylinder</li> </ul>			
Protective caps in place while cylinders are in storage			
<ul> <li>Proper regulators are being used and closed when cylinders are not in use</li> </ul>			
Air Pollution Control Equipment			
<ul> <li>Are there any sources of air emissions other than chemicals being used in the hood?</li> </ul>			
<ul> <li>Is there any air pollution control equipment (vapor recovery systems, cyclones, scrubbers, bag houses, electrostatic precipitators) in use?</li> </ul>			
<ul> <li>If so, are they maintained and maintenance records kept?</li> </ul>			
Housekeeping & Miscellaneous Laboratory Safety			
Bench tops clean, organized and environs maintained to eliminate harmful exposures or unsafe conditions			
<ul> <li>Areas under sinks, window ledges, walls and floors kept orderly, Supplies stored at minimum 6 inches off floor or 18 inches from ceiling</li> </ul>			
<ul> <li>Vacuum lines equipped with traps designed specifically to accumulate/filter the hazardous materials being evacuated. If lab BL-3, does affluent receive heat or chemical treatment prior to disposal</li> </ul>			
<ul> <li>All moving machinery (i.e., vacuum pumps) belts adequately protected by a rigid belt guard or housing</li> </ul>			
All sharps disposed properly			
• The condition of the broken glass box is adequate and placed out of harm's way. Box identified as to contents?			
Electrical Safety			
<ul> <li>High voltage equipment (&gt;600V) labeled, grounded and insulated</li> </ul>			
No equipment has damaged or frayed cords	1		
Extension cords and power are not chained together			

	Yes	No	N/A
<ul> <li>Multiple adaptors used only if they are equipped circuit breakers</li> </ul>	with		
All equipment is grounded via 3-prong plugs			
Plug covers are intact and secure			
<ul> <li>Hot plates and heaters are out of harm's way and monitored.</li> </ul>	1		
• Space heaters are not permitted in laboratory. O areas may have space heaters if they meet Safety Environmental Compliance Department requirement	y &		
Basic Safety			
<ul> <li>Chemical shelves have lips or other type of restra Oxidizers are stored on wooden shelves and sepa from other chemicals</li> </ul>			
Cabinets and bookshelves are secured to the wall			
<ul> <li>Overhead storage is minimized and restrained fro falling</li> </ul>	m		
Heavy equipment is secured or braced from fallin	g		
Respiratory Protection			
Use of respiratory protection conforms to USA gu	idelines		
Respirators are inspected monthly and before any	/ use		
<ul> <li>The user has been fit tested by the Safety &amp; Environmental Compliance Department represent</li> </ul>	ative		
<ul> <li>Cartridges are changed on designated schedule a the appropriate cartridge for the hazard</li> </ul>	nd are		
Laser Safety			
Does the lab use any Class 3b or 4 lasers?			
<ul> <li>Are the lasers registered with the Radiation Safet Department?</li> </ul>	у		
<ul> <li>Are the Standard Precautions for lasers prominen posted for each laser?</li> </ul>	tly		
Are appropriate warning signs and labels posted?			
<ul> <li>Does the lab entrance have a warning light or light sign showing when the laser is in use?</li> </ul>	nted		
Have all workers been trained by the Laser Safety Officer?	/		
<ul> <li>Does the lab have appropriate laser eyewear and been verified by the Radiation Safety Officer</li> </ul>	has this		

	No	N/A
(k		
9		