## **Siemens Optipoint Phone Quick Reference**

Setting up Voice Mail:

- The extension number to reach the Voice Mail system is: 6-1380, DID 461-1380. (There is also a "Voice Mail" key on the handset programmed to dial 6-1380 that will also connect you to the Voice Mail System.)
- The default Security Code is: 0000
- You must complete the entire Voice Mail setup process or you will be required to change the security code each time you enter the Voice Mail setup following each non-completed setup.
- Follow all of the voice prompts, however contrary to the voice instructions, please include your name in your personal greeting.
- The "Mailbox" lamp is similar to the "Mgswt" lamp on the old system.
  - a. Depressing the "Mailbox" button will not connect you to the Voice Mail service.
  - b. Depressing the "Mailbox" button while the "Mailbox" lamp is illuminated by the Voice Mail system will produce the message "Mailbox not Possible" on the handset display.
  - c. When the "Mailbox" lamp is illuminated by the Voice Mail system you must clear your Voice Mail messages in order to tum off the "Mailbox" lamp.
- If you experience problems with your Voice Mail system following the initial setup, please contact Telcom at 460-7114.

#### **Basic Usage control panel:**

### The optiPoint 420 economy/economy plus/standard control panel



Keys for telephone settings

# Standard Key Layout:

The following keys are the default setup for new Siemens Optipoint 420 phones. A complete description of each key function can be found in the online user guide at: - http://www.southalabama.edu/csc/newphones/

Mailbox	Voicemail
Mute	Forward
Speaker	Conference
Pickup 🗮 🛄	Tranșfer
Hold	Connect
$ \begin{array}{c c}                                    $	
	Ln 6-6600

/

s,

### Siemens optiGuide:

-

Features can be activated either by

- pressing a feature key
- selecting an option in the **optiGuide** menu

**optiGuide** is the user-friendly and intuitive user interface on optiPoint phones with Guidance keys A P and LCD display.

#### **Guidance Keys:**

( $\checkmark$ ) The check mark key is used to activate a function or select a feature (ie. enter key) (>) This key allows a user to scroll forward or access the Feature Menus.

(<) This key allows a user to scroll backwards.

# When a user lifts the hand set to initiates a call, the OptiGuide display provides the user with information prompts:

Last number redial? (Appears in display) Saved number? Direct Call Pick Up?

While the phone is active (call placed or call received), by depressing the (>) scroll forward key the following prompts may be accessed:

Start transfer? (Appears in display) Start Conference? Consult? Save Number?

Private Hold? Direct Call Pickup? Park To Station?

#### To Access the Feature Menus, press the (>) scroll forward key:

Speed dial features? Press ( $\checkmark$ ) check mark key to access the following features: Last number redial? (to redial last number you dialed) Station speed dial? (to set up codes to dial personal frequently dialed numbers) Saved number redial?(to redial a number you previously saved) System speed dial?(to use codes to dial company-wide, frequently dialed numbers) Previous menu?

More features? Press ( $\checkmark$ ) check mark key to access the following features: Call forwarding? (to forward calls to another destination) Do not disturb? (to temporarily block incoming calls) Ringer cutoff? (turns telephone ringer off) Previous menu?

<u>View active features?</u> Press ( $\checkmark$ ) check mark key to view the following features: Speaker Call Protect (to show whether you are blocking incoming speaker calls)

<u>**Program/Services?**</u> Press ( $\checkmark$ ) check mark key to access the following features: Destinations? (to create or change destinations)

Press ( $\checkmark$ ) check mark key:

Call Forwarding? (to forward calls to another extension) Press (>) scroll Key:

Fwd Variable All Both? Fwd Variable All Internal? Fwd Variable All External? Fwd Variable Busy both? Return?

Speed Dial Features?(to create personal speed dial list) Saved Number Redial? (to redial a number you have saved) Repdial? (to set up a key for one-touch dialing) Direct Station Select? (to monitor, dial, or answer an extension) Forward Station Number? Return? (returns to previous menu)

Feature Settings (to display or activate features)

Camp-On? (activates delayed call forwarding) Speaker Call Protect? Call Forwarding? Forwarding Station No.? Ringer Cutoff? Return? Use Speed Dialing?

ż

Station Speed Dial: Return?

Key Function

View Feature Key?

Return?

More Features?

Display Suppress On? Show Used Line? Return?

#### Phone Test?

(Led?, Display? Key? Audio Test? Asset ID? Firmware Version? Power Level? Return?)

Cancel? (This will take you completely out of the menu)

Phone Settings? Press (✓) check mark key to access the following features: Ringer volume? Ringer pitch? Display contrast? Speakerphone mode (to reduce echoing from your speakerphone) Warning tone? Rollover volume? Cancel?

## Telephone Reference Guide SIEMENS HiPath 4000

FEATURE	BUTTON / CODE	OPTIGUIDE MENU
HOLD	Press the HOLD button.     To RECONNECT:	<ul> <li>Scroll (&gt;) to and select "Hold?" To RECONNECT:</li> </ul>
Place a caller on hold	Press the line key of the flashing light	Press the line key of the flashing light
TRANSFER Transfer a call	<ul><li>Press TRANSFER (after establishing a call)</li><li>Dial the extension number</li></ul>	<ul> <li>Scroll (&gt;) to and select "Start Transfer?"</li> <li>Dial the extension number</li> </ul>
to another extension	<ul> <li>Announce the call</li> <li>Hang up.</li> <li>To RECONNECT with original caller:</li> <li>Press blinking CONNECT button.</li> </ul>	<ul> <li>Announce the call</li> <li>Hang up.</li> <li>To RECONNECT with original caller:</li> <li>Scroll (&gt;) to and select "Release and Return?"</li> </ul>
CONSULTATION	<ul> <li>Press TRANSFER to put first party on hold</li> </ul>	Select "Consult?"
CALL Consult privately with another party then return to original call	<ul> <li>Dial the second party you wish to speak with</li> <li>Press CONNECT to return to first party (CONNECT may be used to "toggle" between 1<sup>st</sup> and 2<sup>nd</sup> party)</li> </ul>	<ul> <li>Dial the second party you wish to speak with</li> <li>Terminate the call by selecting "<i>Release and Return?</i>" or scroll (&gt;) to and select "<i>Toggle / Connect?</i>" to alternate between callers</li> </ul>
CONFERENCE CALL	<ul> <li>During a call, press TRANSFER</li> <li>Dial the party you want to add and wait for answer</li> <li>Press CONF or TRANSFER to join the call</li> </ul>	<ul> <li>During a call, scroll (&gt;) to and select "Start Conference?"</li> <li>Dial the party you want to add - wait for answer</li> </ul>
Include up to 8 parties into a conference call	<ul> <li>If the party does not answer or does not want to join:</li> <li>Press blinking CONNECT button to rejoin your conference call</li> </ul>	<ul> <li>Select "Conference?" to join the call If the party does not answer or does not want to join:</li> <li>Scroll (&gt;) to and select "Release and Retum?"</li> </ul>
PICK (station)	Press the PICK button (or *3)	Get dial tone
Answer a call that is <b>ringing or</b> on <b>hold</b> at another phone	<ul> <li>Dial the extension of the ringing phone or the extension where the call is holding</li> </ul>	<ul> <li>Scroll (&gt;) to and select "<i>Direct call pickup?</i>"</li> <li>Dial the extension of the ringing phone or held call</li> </ul>
PICK (group)	Press the <b>PICK</b> button twice (or **3)	Not available
Answer a call that is <b>ringing</b> within your pickup group (set up by your administrator)	<ul> <li>It is not necessary to know the extension of the ringing phone</li> </ul>	
LAST NUMBER	• Dial # # 4	Get dial tone and select "Last number redial?"
REDIAL (LNR) Redial the last number dialed		
SAVED NUMBER	Dial # 4 while phone is ringing – number is stored	During the call, scroll (>) to and select "Save
REDIAL (SNR)	To redial the saved number:	Number?"
Redial the last saved number	• Dial # 4	To redial the saved number:
		<ul> <li>Get dial tone</li> <li>Scroll (&gt;) to and select "Saved Number Redial?"</li> </ul>
FORWARD Temporarily redirect calls to another destination	<ul> <li>Get dial tone on the line you wish to forward</li> <li>Press the FORWARD button (or # 91)</li> <li>Dial the forwarding target number</li> <li>Press ✓ or # (The light will flicker next to the line you have forwarded)</li> <li>To Cancel Forwarding:</li> <li>Press the FORWARD button (or ## 91)</li> </ul>	<ul> <li>Scroll (&gt;) to and select "More Features?"</li> <li>Select "Call Forwarding?" and follow prompts To Cancel Forwarding:</li> <li>Scroll (&gt;) to and select "View Active Features?"</li> <li>Select "Deact Call Forwarding?"</li> </ul>
SYSTEM SPEED	• Press # 61	• Scroll (>) to and select "Speed Dial Features?"
System wide directory of frequently dialed numbers	Dial the index code     Note: Applicable only if enabled by your administrator	<ul> <li>Scroll (&gt;) to and select "System Speed Dial?"</li> <li>Dial the index code</li> </ul>

FEATURE	BUTTON / CODE	OPTIGUIDE MENU
STATION SPEED	To Program:	To Program:
Personal directory of frequently dialed EXTERNAL numbers	• Press # # 3	• Scroll (>) to and select "Program/Service?"
	Enter the index code (00-29)	Select "Destinations?"
	Enter desired number	Select "Speed Dial Features?"
	<ul> <li>Press ✓ to save</li> </ul>	Dial index code (00-29)
	To Call:	Enter desired number
	Press #3	<ul> <li>Press ✓ to save</li> </ul>
	Dial the index code (00-29)	To Call:
		• Scroll (>) to and select "Speed Dial Features?"
		Select "Station Speed Dial?"
		Dial the index code (00-29)
DO NOT	Press the DND button	Scroll (>) to and select "More Features?"
DISTURB (DND)	To Cancel DND:	<ul> <li>Scroll to and select "Do Not Disturb?"</li> </ul>
. ,	Press the DND button	To Cancel DND;
Disables ringer and sends callers directly to voicemail		Scroll (>) to and select "View Active
		Features?"
		Select "Do Not Disturb Off?"
CALLBACK	Listen for busy signal	• Listen for busy signal and select "Callback?"
REQUEST	• Dial # 1	Phone will call back with triple rings
Automatic callback notification	Hang up	Answer phone – originally dialed extension will
when busy line becomes free	Phone will call back with triple rings	be dialed again
-	Answer phone – originally dialed extension will be	To cancel callback request:
	dialed again	<ul> <li>Scroll (&gt;) to and select "View Active</li> </ul>
	To cancel caliback request	Features?"
	<ul> <li>Dial # # 1 – hang up</li> </ul>	<ul> <li>Scroll (&gt;) to and select "View Callbacks Sent?</li> </ul>
		Follow prompts to cancel callback request
REPDIAL	<ul> <li>Program using the OptiGuide menu</li> </ul>	<ul> <li>Scroll (&gt;) to and select "Program/Service?"</li> </ul>
Program a frequently dialed		Press a blank Repdial button
number or feature code into a	To dial a programmed number.	Dial the number or feature code
blank button	<ul> <li>Press the corresponding REPDIAL key</li> </ul>	Select "Save?"

AUDIO SETTINGS A		
	<ul> <li>Press the + or – button next to the keypad</li> <li>Press 1 or ✓</li> <li>Press the + or – button for the desired volume</li> <li>Press ✓ to save</li> </ul>	
RING PITCH	<ul> <li>Press the + or - button next to the keypad</li> <li>Press 2 or ✓</li> <li>Press the + or - button for the desired ring pitch (16 to choose from)</li> <li>Press ✓ to save</li> </ul>	

optiGuide	
	All display phones contain optiGuide, an application organizing phone features into visible menu items and options
	Use the left and right arrows for scrolling through the options.
	Use the checkmark to select an option.